Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples		Deprecated Version Tracking		
	Colour Code Lagand						Label	ID	Description/Gui
	Colour Code Legend field name in yellow = required					IMPORTANT:			dance
	note hamo in yourse.					Only labels			
						and/or IDs will be deprecated.			
						always with			
						replacement			
						version provided. If a			
						term changes			
						in its meaning, a new term will			
						be created.			
	field name in purple = recommended								
	field name in white = optional								
Database identifiers		GENEPIO:0001122							
Database identifiers	specimen collector sample ID	GENEPIO:0001123	The user-defined name for the sample.	Store the collector sample ID. If this number is considered identifiable information, provide an alternative ID. Be sure to store the key that maps between the original and alternative IDs for traceability and follow up if necessary, Every collector sample ID from a single submitter must be unique. It can have any format, but we suggest that you make it concise, unique and consistent within your law.			1.0.0	1.0.0	1.0.0
Database identifiers	specimen collector subsample ID	GENEPIO:0100752	The user-defined identifier assigned to a portion of the original sample.	Store the ID for the subsample/aliquot.	ASDFG123_12		1.0.0	1.0.0	1.0.0
Database identifiers	pooled sample ID	GENEPIO:0100996	The user-defined identifier assigned to a combined (pooled) set of samples.	If the sample being analyzed is the result of pooling individual samples, rename the pooled sample with a new identifier. Store the pooled sample ID.	12345AYZ		1.0.0	1.0.0	1.0.0
Database identifiers	metagenome-assembled genome (MAG) ID		The user-defined identifier assigned to a	Store the MAG ID.	XYZ1234.1		1.0.0	1.0.0	1.0.0
		GENEPIO:0100753	genome reconstructed from metagenomic data.						
Database identifiers	specimen collector project ID	GENEFIO:0100733		a If the sample was collected or analyzed under the umbrella			1.0.0	1.0.0	1.0.0
Balabase lashaners	oposition defication project is	GENEPIO:0100918	sequencing project.	of a specific project, include the name of that project here.			1.0.0	1.0.0	1.0.0
Database identifiers	BioProject accession	GENEPIO:0001136	The INSDC (i.e., ENA, NCBI, or DDBJ) accession number of the BioProject(s) to which the BioSample belongs.	Store the BioProject accession number. BioProjects are an organizing tool that links together raw sequence data, assemblies, and their associated metadata. Each province will be assigned a different bioproject accession number by the National Microbiology Lab. A vallaf (NSI BioProject accession has prefix PRJN e.g., PRJNA12345, and is			1.0.0	1.0.0	1.0.0
Database identifiers	BioSample accession	GENEPIO:0001139	The identifier assigned to a BioSample in INSDC (i.e., ENA, NCBI, or DDBJ) archives.		SAMN14180202, SAMD00000001, SAME		1.0.0	1.0.0	1.0.0
Database identifiers	GenBank accession	GENEPIO:0100754	The unique identifier assigned to an assembly or consensus sequence in	ENA have the prefix SAMEA, DDBJ have SAMD Store the versioned GenBank accession assigned to the submitted sequence.	LZ986655.1		1.0.0	1.0.0	1.0.0
Database identifiers	SRA accession	GENEPIO:0100754 GENEPIO:0001142	The Sequence Read Archive (SRA) identifies	'	SRR11177792		1.0.0	1.0.0	1.0.0
Database identifiers	SKA accession	GENEPIO.0001142	linking raw read data, methodological metadata and quality control metrics submitted to the INSDC.	NCBI-SRA accessions start with SRR.	SRR111/1/92		1.0.0	1.0.0	1.0.0
Database identifiers	GISAID accession	GENEPIO:0001147	The identifier assigned to a sequence in GISAID (the Global Initiative on Sharing All Influenza Data) archives.	Store the accession assigned to the submitted sequence. GISAID accessions start with EPI.	EPI_ISL_402131		1.0.0	1.0.0	1.0.0
Database identifiers	GISAID virus name	GENEPIO:0100282	The user-defined GISAID virus name assigned to the sequence.	GISAID virus names should be in the format "hCoV-19/Country/Identifier/year".	hCoV-19/Canada/prov_rona_99/2020		1.0.0	1.0.0	1.0.0
Database identifiers	ENA accession	GENEPIO:0100755	The identifier assigned to a sequence in the European Nucleotide Archive (ENA).	ENA sequence accessions start with ERR.	ERR123456		1.0.0	1.0.0	1.0.0
Database identifiers	DRA accession	GENEPIO:0100757	The identifier assigned to a sequence in DNA Data Bank of Japan (DDBJ) archives.	Store the accession assigned to the submitted sequence. DRA accessions start with DRR.	DRR123456		1.0.0	1.0.0	1.0.0
Database identifiers	GSA accession	GENEPIO:0100758	The identifier assigned to a BioSample in GSA (Genome Sequence Archive) archives.		CRR123456		1.0.0	1.0.0	1.0.0
Database identifiers	Enterobase accession	GENEPIO:0100759	The identifier assigned to a sequence in Enterobase archives.	Store the barcode assigned to the submitted sequence. Enterobase barcodes start with different 3 letter codes depending on the organism.	SAL_AA0019AA_ST		1.0.0	1.0.0	1.0.0
Database identifiers	sampling site ID	GENEPIO:0100760	The user-defined identifier assigned to a specific location from which samples are taken.	Store the ID for the site from which a sample was taken. The "site" is user defined (e.g. it may be a building and its environs, a specific entity within an environment). Please use the same site ID for all samples from a given site, regardless of when these samples were taken. Any important changes in site location, should be represented with a new site ID.	Site 12A		1.0.0	1.0.0	1.0.0
Database identifiers	sampling event ID	GENEPIO:0100761	The user-defined identifier assigned to a specific event during which one or more samples are taken, from one or more sites.	Store the ID for the event during which a sample or samples were taken. For example, an event could be one person taking samples from multiple sites, or multiple people taking samples from one site.	Event 120522.1		1.0.0	1.0.0	1.0.0
Sample collection and processing	ng	GENEPIO:0001150							

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated	Version Tracking		
FareIII Class		Ontology Identifier	Dennition	Guidance	Examples	Lanel	עור	Label	ID	Description/Gu
Sample collection and processing	Colour Code Legend sample collection data steward name	GENEPIO:0100762	A sample collection data field which describes the name of the individual responsible for the data governance, (meta)data usage and distribution of the sample.	Provide the name of the sample collection data steward.	Joe Bloggs			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample collected by	GENEPIO:0001153		The name of the agency should be written out in full, (with minor exceptions) and be consistent across multiple submissions	Public Health Agency of Canada			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample collector contact email	GENEPIO:0001156	The email address of the contact responsible for follow-up regarding the sample.	The email address can represent a specific individual or lab e.g. johnnyblogs@lab.ca, or RespLab@lab.ca	WaterTester@facility.ca			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc name (country)	GENEPIO:0001181	The country of origin of the sample.	If known, select a value from the pick list.	Canada			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc name (state/province/territory)	GENEPIO:0001185	The state/province/territory of origin of the sample.	Provide the state/province/territory name from the GAZ geography ontology. Search for geography terms here: https://www.ebi.ac.uk/ols/ontologies/gaz	Western Cape			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc name (county/region)	GENEPIO:0100280	The county/region of origin of the sample.	Provide the county/region name from the GAZ geography ontology. Search for geography terms here: https://www.ebi.ac.uk/ols/ontologies/gaz	Derbyshire			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc name (city)	GENEPIO:0001189	The city of origin of the sample.	Provide the city name from the GAZ geography ontology. Search for geography terms here: https://www.ebi.ac.uk/ols/ontologies/gaz	Vancouver			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc name (site)	GENEPIO:0100436	The name of a specific geographical location e.g. Credit River (rather than river).	Provide the name of the specific geographical site using a specific noun (a word that names a certain place, thing).	Credit River			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc latitude	GENEPIO:0100309	The latitude coordinates of the geographical location of sample collection.	Provide latitude coordinates if available. Do not use the centre of the city/region/province/state/country or the location of your agency as a proxy, as this implicates a real location and is misleading. Specify as degrees latitude in format *tigl.dddfyllS**.	38.98 N			1.0.0	1.0.0	1.0.0
Sample collection and processing	geo loc longitude	GENEPIO:0100310	The longitude coordinates of the geographical location of sample collection.	Provide longitude coordinates if available. Do not use the centre of the city/region/province/state/country or the location of your agency as a proxy, as this implicates a real location and is misleading. Specify as degrees longitude in format "cifd.dddd WIE".	77 11 W			1.0.0	1.0.0	1.0.0
Sample collection and processing	watershed shapefile availability	GENEPIO:0100919	descriping the catchment contributing to a watershed.	Select a value from the picklist to describe whether or not a watershed shapefile would be available upon request.				1.0.0	1.0.0	1.0.0
Sample collection and processing	watershed shapefile filename	GENEPIO:0100920	The name of the watershed shapefile.	Provide the shapefile filename corresponding to the watershed from which the sample was taken. If there are multiple files associated with the watershed, provide all names separated by commas.	siteAD17.shp, siteAD17.kml			1.0.0	1.0.0	1.0.0
Sample collection and processing	organism	GENEPIO:0001191	Taxonomic name of the organism.	Provide the official nomenclature for the organism present in the sample. Search for taxonomic names here: ncbi.nlm.nih.gov/laxonomy.	Severe acute respiratory syndrome coron-	a		1.0.0	1.0.0	1.0.0
Sample collection and processing	purpose of sampling	GENEPIO:0001198	The reason that the sample was collected.	The reason a sample was collected may provide information about potential biases in sampling strategy. Provide the purpose of sampling from the picklist in the template. Most likely, the sample was collected for public health surveillance. The reason why a sample was originally collected may differ from the reason why it was selected for sequencing, which should be indicated in the "purpose of sequencing" fellow.	Public health surveillance			1.0.0	1.0.0	1.0.0
Sample collection and processing	scale of sampling	GENEPIO:0100877	The range of locations or entities sampled expressed in general terms.	Provide the scale of wastewater sampling by selecting a value from the picklist.	Community-level surveillance			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample received date	GENEPIO:0001179	The date on which the sample was received.	Provide the sample received date in ISO 8601 format, i.e. "YYYY-MM-DD".	2020-03-28			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample collection date	GENEPIO:0001174	The date on which the sample was collected or sampling began for a continuous sample.	If your sample is a continuous sample please use this field				1.0.0	1.0.0	1.0.0
Sample collection and processing	sample processing date	GENEPIO:0100763	The date on which the sample was processed.	Provide the sample processed date in ISO 8601 format, i.e. "YYYY-MM-DD". The sample may be collected and processed (e.g. filtered, extraction) on the same day, or on different dates	2020-03-16			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample collection time	GENEPIO:0100764	The time at which the sample was collected.	If a sample was collected over a certain time period, provide the end time here and the duration of the collection in the field "sample collection duration value". Provide this time in ISO 8601 24hr format, including the time zone with respect to UTC. Format, "HH:MM:SS+[Hours+/-UTC]" e.g. 11:23pm Pacific Daylight Savings Time should be recorded as 23:23:00-07:00.				1.0.0	1.0.0	1.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples			Tracking		D 111 10
	Colour Code Legend							Label	ID	Description/Gui dance
Sample collection and processing	sample collection time of day	GENEPIO:0100765	The descriptive time of day during which the sample was collected.	If known, fill in sample collection time. Otherwise, select a value from the pick list for sample collection time of day to approximate the timing. The time of sample processing matters especially for grab samples, as fecal concentration in wastewater fluctuates over the course of the day.	Morning			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample collection time duration value	GENEPIO:0100766	The amount of time over which the sample was collected.	Provide the numerical value of time.	4			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample collection time duration unit	GENEPIO:0100767	The units of the time duration measurement of sample collection.	Provide the units from the pick list.	Hour			1.0.0	1.0.0	1.0.0
Sample collection and processing	presampling activity	GENEPIO:0100433	The activities or variables upstream of sample collection that may affect the sample	If there was an activity that would affect the sample prior to collection (this is different than sample processing), provide the activities by selecting one or more values from the template pick list. If the information is unknown or cannot be provided, leave blank or provide a null value.				1.0.0	1.0.0	1.0.0
Sample collection and processing	presampling activity details	GENEPIO:0100434	The details of the activities or variables that affected the sample collected.	Briefly describe the presampling activities using free text.	Agricultural waste from large farm contributes waste to the site sampled.			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample volume measurement value	GENEPIO:0100768	The numerical value of the volume measurement of the sample collected.	Provide the numerical value of volume.	5			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample volume measurement unit	GENEPIO:0100769	The units of the volume measurement of the sample collected.	Provide the units from the pick list.	mL			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample storage method	GENEPIO:0100448	The process used to store the sample.	Provide details of how the sample was stored from time of collection until time of processing. If there were issues with the cold chain storage, note those here.	The sample was placed in a tube in a cooler bag during transportation (~3 hours) to the lab site. At this point the sample was placed in storage medium and put in a -10C freezer until it was processed and extracted 5 days later.			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample storage medium	GENEPIO:0100449	The medium in which a sample is stored.	Provide the name of the transport medium or storage medium used for this sample. If none was used, leave blank or write "None".	Cary-Blair transport medium			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample storage duration value	GENEPIO:0101014	The numerical value of the time measurement during which a sample is in storage.	Provide the numerical value of time.	5			1.0.0	1.0.0	1.0.0
Sample collection and processing	sample storage duration unit	GENEPIO:0101015	The units of a measured sample storage duration.	Provide the units from the pick list.	Day			1.0.0	1.0.0	1.0.0
Sample collection and processing	specimen processing	GENEPIO:0001253	Any processing applied to the sample during or after receiving the sample.	Select processes from the picklist that were applied to this sample.	Centrifugation			1.0.0	1.0.0	1.0.0
Sample collection and processing	specimen processing details	GENEPIO:0100311	The details of the processing applied to the sample during or after receiving the sample.	Briefly describe the processes applied to the sample.	25 samples were pooled and further prepared as a single sample during librar prep.	ту		1.0.0	1.0.0	1.0.0
Sample collection and processing	experimental protocol field	GENEPIO:0101029	The name of the overarching experimental methodology that was used to process the	Provide the name of the methodology used in your study. If available, provide a link to the protocol.						
Sample collection and processing	environmental site	GENEPIO:0001232	An environmental location may describe a site in the natural or built environment e.g. contact surface, metal can, hospital, wet market, bat cave.	Provide a descriptor of the environmental site sampled. Use the picklist provided in the template. If not applicable, choose a null value.	Meat processing plant		•	1.0.0	1.0.0	1.0.0
Sample collection and processing	environmental material	GENEPIO:0001223	A substance obtained from the natural or man-made environment e.g. soil, water, sewage.	Provide a descriptor of the environmental material sampled. Use the picklist provided in the template. If not applicable, choose a null value.	Raw wastewater			1.0.0	1.0.0	1.0.0
Sample collection and processing	environmental material properties	GENEPIO:0100770	The properties, characteristics and qualities of a substance obtained from an environment.	Provide the environmental material properties by selecting descriptors from the pick list.	Stagnant			1.0.0	1.0.0	1.0.0
Sample collection and processing	wastewater system type	GENEPIO:0100771	The type or classification of a wastewater system e.g. sanitary sewer, combined sewer	Provide the classification of the wastewater system by selecting from the provided pick list.	Sanitary sewer			1.0.0	1.0.0	1.0.0
Sample collection and processing	experimental control type	GENEPIO:0100921	The type of control that the sample represents in the experiment.	This field is used to distinguish samples under study from controls. A sample may act as an experimental control if it is used to detect experimental errors or to ensure experimental methods are performing as expected. If the sample acted as an experimental control speed can experimental control type from the picklist. If the sample was not a control, leave blank or select "Not Applicable".	Positive experimental control		,	1.0.0	1.0.0	1.0.0
Sample collection and processing	experimental control details	GENEPIO:0100922	The details regarding the type of control that the sample represents in the experiment.	Provide details regarding the nature of the reference strain used as a control, or what is was used to monitor.	Human coronavirus 229E (HCoV-229E) spiked in sample as process control			1.0.0	1.0.0	1.0.0
Sample collection and processing	collection device	GENEPIO:0001234	The instrument or container used to collect the sample e.g. grab sampler.	Provide a descriptor of the device used for sampling. Use the picklist provided in the template. If not applicable, choose a null value.	Automatic flow-proportional sampler			1.0.0	1.0.0	1.0.0
Sample collection and processing	collection method	GENEPIO:0001241	The process used to collect the sample.	Provide a descriptor of the collection method used for sampling. Use the picklist provided in the template. If not applicable, choose a null value.	Automatic composite sampling		,	1.0.0	1.0.0	1.0.0
Sample collection and processing	nucleic acid extraction method	GENEPIO:0100939	The process used to extract genomic material from a sample.	Briefly describe the extraction method used.	Direct wastewater RNA capture and purification via the "Sewage, Salt, Silica and SARS-CoV-2 (4S)" method v4 found at https://www.protocols.io/view/v-4-direct-wastewater-ma-capture-and-purification-36 wgq581ygk5/v4	v		1.0.0	1.0.0	1.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Deprecated Label ID	Version Tracking	ID	Docorieties (C
	Colour Code Legend						Label	טו	Description/Go dance
Sample collection and processing	nucleic acid extraction kit	GENEPIO:0100772	The kit used to extract genomic material from a sample	Provide the name of the genomic extraction kit used.	QIAamp PowerFecal Pro DNA Kit		1.0.0	1.0.0	1.0.0
Sample collection and processing	endogenous control details	GENEPIO:0100923	The description of the endogenous controls included when extracting a sample.	Provide the names of endogenous controls that were used as a reference during extraction. If relevant, include titers of these controls, as well as whether any controls were expected but not identified in the sample.			1.0.0	1.0.0	1.0.0
Sample collection and processing	extraction recovery efficiency measurement value	GENEPIO:0100924	The recovery efficiency of an extraction, calculated as the amount of a synthetic or endogenous compound identified in the sample relative to the amount expected.	Provide value as a percent.	25		1.0.0	1.0.0	1.0.0
Sample collection and processing	extraction recovery efficiency measurement method	GENEPIO:0100925	The method by which recovery efficiency of an extraction was calculated.	Provide a brief description of how extraction recovery efficiency was measured or estimated.	Spiked in synthetic material into wastewater sample and into water contro	d	1.0.0	1.0.0	1.0.0
Environmental conditions and		GENEPIO:0100940			and compared recovery.				
measurements									
Environmental conditions and neasurements	water catchment area human population measurement value	GENEPIO:0100773	The numerical value of the human population measurement that contributes to the composition of water in a catchment area.	Where known, provide the numerical value of population size, i.e. the number of people.	10,500		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	water catchment area human population bin	GENEPIO:0100774	The human population range of the water catchment that contributes effluent to a wastewater site.	Where catchment population is not well known, provide an estimation of population size by selecting a value from the picklist.	1,000 - 10,000 people		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	water catchment area human population measurement method	GENEPIO:0100775	The method by which a water catchment 's human population size was measured or estimated	Provide a brief description of how catchment population size was measured or estimated.	population of jurisdiction encompassing the wastewater service area		1.0.0	1.0.0	1.0.0
Environmental conditions and	water catchment area human population density	GENEPIO:0100776	The numerical value describing the number	Provide the numerical value of the population density in the	4		1.0.0	1.0.0	1.0.0
Environmental conditions and	water catchment area human population density	GENEPIO:0100777	The unit describing the number of humans	Provide the unit of the population density in the catchement			1.0.0	1.0.0	1.0.0
Environmental conditions and	populated area type	GENEPIO:0100778	A type of area that is populated by humans	Provide the populated area type from the pick list.	Urban area		1.0.0	1.0.0	1.0.0
Environmental conditions and	sampling weather conditions	GENEPIO:0100779	The state of the atmosphere at a place and	Provide the weather conditions at the time of sample	Rain		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements Environmental conditions and	presampling weather conditions	GENEPIO:0100780 GENEPIO:0100911	Weather conditions prior to collection that may affect the sample.	·	Drizzle		1.0.0	1.0.0	1.0.0
measurements	precipitation measurement value		a precipitation process.	to the time of sample collection.	12				
Environmental conditions and measurements	precipitation measurement unit	GENEPIO:0100912	The units of measurement for the amount of water which has fallen during a precipitation process.	Provide the units of precipitation by selecting a value from the pick list.	inch		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	precipitation measurement method	GENEPIO:0100913		Provide the name of the procedure or method used to measure precipitation.	Rain gauge over a 12 hour period prior to sample collection		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	ambient temperature measurement value	GENEPIO:0100935	The numerical value of a measurement of the ambient temperature.	Provide the numerical value of the measured temperature.	70		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	ambient temperature measurement unit	GENEPIO:0100936	The units of a measurement of the ambient temperature.	Provide the units of the measured temperature.	degree Celsius (C)		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	pH measurement value	GENEPIO:0001736	The measured pH value indicating the acidity or basicity(alkalinity) of an aqueous solution.	Provide the numerical value of the measured pH.	7.4		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	pH measurement method	GENEPIO:0100781	The process used to measure pH value.	Provide the name of the procedure or technology used to measure pH.	pH test strip (litmus test)		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total daily flow rate measurement value	GENEPIO:0100905	The numerical value of a measured fluid flow rate over the course of a day.	Provide the numerical value of the measured flow rate.	10		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total daily flow rate measurement unit	GENEPIO:0100906	The units of a measured fluid flow rate over the course of a day.	Provide the units of the measured flow rate by selecting a value from the pick list.	million gallons per day (MGD)		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total daily flow rate measurement method	GENEPIO:0100907	The process used to measure total daily fluid flow rate.	Provide the name of the procedure or technology used to measure flow rate.	Flow meter		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	instantaneous flow rate measurement value	GENEPIO:0100908	The numerical value of a measured instantaneous fluid flow rate.	Provide the numerical value of the measured flow rate.	25		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	instantaneous flow rate measurement unit	GENEPIO:0100909	The units of a measured instantaneous fluid flow rate.	Provide the units of the measured flow rate by selecting a value from the pick list.	cubic meter per hour (m^3/h)		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	instantaneous flow rate measurement method	GENEPIO:0100910	fluid flow rate.	Provide the name of the procedure or technology used to measure flow rate.	Flow meter		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	turbidity measurement value	GENEPIO:0100783	The numerical value of a measurement of turbidity.	Provide the numerical value of the measured turbidity.	0.02		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	turbidity measurement unit	GENEPIO:0100914	The units of a measurement of turbidity.	Provide the units of the measured turbidity by selecting a value from the pick list.	nephelometric turbidity unit (NTU)		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	turbidity measurement method	GENEPIO:0101013	The process used to measure turbidity.	Provide the name of the procedure or technology used to measure turbidity.	Nephelometric method		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	dissolved oxygen measurement value	GENEPIO:0100915	The numerical value of a measurement of dissolved oxygen.	Provide the numerical value of the measured dissolved oxygen.	5		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	dissolved oxygen measurement unit	GENEPIO:0100784	The units of a measurement of dissolved oxygen.	Provide the units of the measured dissolved oxygen by selecting a value from the pick list.	part per million (ppm)		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	dissolved oxygen measurement method	GENEPIO:0100785	The method used to measure dissolved oxygen.	Provide the name of the procedure or technology used to measure dissolved oxygen.	Dissolved oxygen meter in vertical direction		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	oxygen reduction potential (ORP) measurement	GENEPIO:0100917	The numerical value of a measurement of oxygen reduction potential (ORP).	Provide the numerical value of the measured oxygen reduction potential.	-50		1.0.0	1.0.0	1.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking		
	Colour Code Legend							Label	ID	Description/Gui dance
Environmental conditions and measurements	oxygen reduction potential (ORP) measurement unit	GENEPIO:0100786	The units of a measurement of oxygen reduction potential (ORP).	Provide the units of the measured oxygen reduction potential by selecting a value from the pick list.	milliVolt (mV)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	oxygen reduction potential (ORP) measurement method	GENEPIO:0100787	The method used to measure oxygen reduction potential (ORP).	Provide the name of the procedure or technology used to measure oxygen reduction potential.	ORP sensor			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	chemical oxygen demand (COD) measurement value	GENEPIO:0100788	The measured value from a chemical oxygen demand (COD) test.	Provide the numerical value of the COD test result.	26			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	chemical oxygen demand (COD) measurement unit	GENEPIO:0100789	The units associated with a value from a chemical oxygen demand (COD) test.	Provide the units of the COD test result.	milligram per liter (mg/L)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	chemical oxygen demand (COD) measurement method	GENEPIO:0100790	The method used to measure chemical oxygen demand (COD).	Provide the name of the procedure or technology used to measure COD.	Hach LCK test kit			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	carbonaceous biochemical oxygen demand (CBOD) measurement value	GENEPIO:0100791	The numerical value of a measurement of carbonaceous biochemical oxygen demand (CBOD).	Provide the numerical value of the measured CBOD.	20			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	carbonaceous biochemical oxygen demand (CBOD) measurement unit	GENEPIO:0100792	The units of a measurement of carbonaceous biochemical oxygen demand (CBOD).	Provide the units of the measured CBOD by selecting a value from the pick list.	milligram per liter (mg/L)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	carbonaceous biochemical oxygen demand (CBOD) measurement method	GENEPIO:0100793	The method used to measure carbonaceous biochemical oxygen demand (CBOD).	Provide the name of the procedure or technology used to measure CBOD.	CBOD measurement by optical probe			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total suspended solids (TSS) measurement value	GENEPIO:0100794	The mass of suspended particulates, both organic and inorganic in a sample.	Provide the numerical value of the measured TSS.	8			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total suspended solids (TSS) measurement unit	GENEPIO:0100795	The units associated with a value from a total suspended solids (TSS) test.	Provide the units of the measured TSS.	percent (%)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total suspended solids (TSS) measurement method	GENEPIO:0100796	The method used to measure total suspended solids (TSS).	Provide the name of the procedure or technology used to measure TSS.	Vacuum filter through a 2-micron filter, then oven-dried and weighed sample			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total dissolved solids (TDS) measurement value	GENEPIO:0100797	The numerical value from a total dissolved solids (TDS) test.	Provide the numerical value of the measured TDS.	2			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total dissolved solids (TDS) measurement unit	GENEPIO:0100798	The units associated with a value from a total dissolved solids (TDS) test.	Provide the units of the measured TDS.	percent (%)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total dissolved solids (TDS) measurement method	GENEPIO:0100799	The method used to measure total dissolved solids (TDS).	Provide the name of the procedure or technology used to measure TDS.	Subtract calculated TSS from calculated TS			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total solids (TS) measurement value	GENEPIO:0100800	The numerical value from a total solids (TS) test.	Provide the numerical value of the measured TS.	10			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total solids (TS) measurement unit	GENEPIO:0100801	The units associated with a value from a total solids (TS) test.	Provide the units of the measured TS.	percent (%)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total solids (TS) measurement method	GENEPIO:0100802	The method used to measure total solids (TS).	Provide the name of the procedure or technology used to measure TS.	Gravimetric method by oven drying, then weighing			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	alkalinity measurement value	GENEPIO:0100878	The numerical value of a measurement of alkalinity.	Provide the numerical value of the measured alkalinity.	3			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	alkalinity measurement unit	GENEPIO:0100879	The units of a measurement of alkalinity.	Provide the units of the measured alkalinity.	milligram per liter of calcium carbonate (mg/L CaCO3)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	alkalinity measurement method	GENEPIO:0100880	The process used to measure alkalinity.	Provide the name of the procedure or technology used to measure alkalinity.	Titration method			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	conductivity measurement value	GENEPIO:0100916	The numerical value of a measurement of conductivity.	Provide the numerical value of the measured conductivity.	1412			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	conductivity measurement unit	GENEPIO:0100803	The units of a measurement of conductivity.	Provide the units of the measured conductivity.	microSiemen per centimeter (μS/cm)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	conductivity measurement method	GENEPIO:0100804	The method used to measure conductivity.	Provide the name of the procedure or technology used to measure conductivity.	Conductivity electrode and meter			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	salinity measurement value	GENEPIO:0100805	The numerical value of a measurement of salinity.	Provide the numerical value of the measured salinity.	35			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	salinity measurement unit	GENEPIO:0100806	The units of a measurement of salinity.	Provide the units of the measured salinity.	practical salinity unit (PSU)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	salinity measurement method	GENEPIO:0100807	The method used to measure salinity.	Provide the name of the procedure or technology used to measure salinity.	conductivity meter			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total nitrogen (TN) measurement value	GENEPIO:0100808	The numerical value of a measurement of total nitrogen (TN).	Provide the numerical value of the measured TN.	120			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total nitrogen (TN) measurement unit	GENEPIO:0100809	The units of a measurement of total nitrogen (TN).	Provide the units of the measured TN.	milligram per liter (mg/L)			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total nitrogen (TN) measurement method	GENEPIO:0100810	The method used to measure total nitrogen (TN).	Provide the name of the procedure or technology used to measure TN.	Hach total nitrogen spectrophotometric test			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total phosphorus (TP) measurement value	GENEPIO:0100811	The numerical value of a measurement of total phosphorus (TP).	Provide the numerical value of the measured TP.	2			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total phosphorus (TP) measurement unit	GENEPIO:0100812	The units of a measurement of total phosphorus (TP).	Provide the units of the measured TP.	milligrams orthophosphate as phosphorus per liter (mg PO4-P/L)	s		1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	total phosphorus (TP) measurement method	GENEPIO:0100813	The method used to measure total phosphorus (TP).	Provide the name of the procedure or technology used to measure TP.	Merck phosphate spectrophotometric test kit			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	fecal contamination indicator	GENEPIO:0100814	A gene, virus, bacteria, or substance used to measure the sanitary quality of water in regards to fecal contamination.	If a fecal contamination indicator was measured, select it from the picklist.	crAssphage			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	fecal contamination value	GENEPIO:0100815	The numerical value of a measurement of fecal contamination.	Provide the numerical value of the measured fecal contamination.	10			1.0.0	1.0.0	1.0.0
Environmental conditions and measurements	fecal contamination unit	GENEPIO:0100816	The units of a measurement of fecal contamination.	Provide the units of the measured fecal contamination.	cycle threshold (Ct) / quantification cycle (Cq)			1.0.0	1.0.0	1.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Tracking		
	Colour Code Legend							Label	ID	Description/G dance
Environmental conditions and neasurements	fecal contamination method	GENEPIO:0100817	The method used to measure fecal contamination.	Provide the name of the procedure or technology used to measure fecal contamination.	quantitative PCR assay			1.0.0	1.0.0	1.0.0
nvironmental conditions and neasurements	fecal coliform count value	GENEPIO:0100818	The numerical value of a measurement of fecal coliforms within a sample.	Provide the numerical value of the measured fecal coliforms.	3			1.0.0	1.0.0	1.0.0
nvironmental conditions and neasurements	fecal coliform count unit	GENEPIO:0100819	The units of a measurement of fecal coliforms.	Provide the units of the measured fecal coliforms.	most probable number per milliliter (MPN/mL)			1.0.0	1.0.0	1.0.0
Environmental conditions and neasurements	fecal coliform count method	GENEPIO:0100820	The method used to measure fecal coliforms	. Provide the name of the procedure or technology used to measure fecal coliforms.	MPN method via serial dilutions until lack of growth			1.0.0	1.0.0	1.0.0
Environmental conditions and neasurements	urinary contamination indicator	GENEPIO:0100837	A gene, virus, bacteria, or substance used to measure the sanitary quality of water in regards to urinary contamination.	If a urinary contamination indicator was measured, select it from the picklist.	3			1.0.0	1.0.0	1.0.0
Environmental conditions and neasurements	urinary contamination value	GENEPIO:0100838	The numerical value of a measurement of urinary contamination.	Provide the numerical value of the measured urinary contamination.	3			1.0.0	1.0.0	1.0.0
invironmental conditions and neasurements	urinary contamination unit	GENEPIO:0100839	The units of a measurement of urinary contamination.	Provide the units of the measured urinary contamination.	nanograms per liter			1.0.0	1.0.0	1.0.0
invironmental conditions and neasurements	urinary contamination method	GENEPIO:0100840	The method used to measure urinary contamination.	Provide the name of the procedure or technology used to measure urinary contamination.				1.0.0	1.0.0	1.0.0
invironmental conditions and	sample temperature value (at collection)	GENEPIO:0100821	The numerical value of a measurement of temperature of a sample at collection.	Provide the numerical value of the measured temperature.	20			1.0.0	1.0.0	1.0.0
Environmental conditions and neasurements	sample temperature unit (at collection)	GENEPIO:0100822	The units of a measurement of temperature of a sample at the time of collection.	Provide the units of the measured temperature.	degree Celsius (C)			1.0.0	1.0.0	1.0.0
Environmental conditions and	sample temperature value (when received)	GENEPIO:0100823	The numerical value of a measurement of	Provide the numerical value of the measured temperature.	22			1.0.0	1.0.0	1.0.0
measurements Environmental conditions and measurements	sample temperature unit (when received)	GENEPIO:0100824	temperature of a sample upon receipt. The units of a measurement of temperature of a sample at the time upon receipt.	Provide the units of the measured temperature.	degree Celsius (C)			1.0.0	1.0.0	1.0.0
Sequence information		GENEPIO:0001441	or a sample at the time upon receipt.							
Sequence information	purpose of sequencing	GENEPIO:0001445	The reason that the sample was sequenced.	The reason why a sample was originally collected may differ from the reason why it was selected for sequencing. The reason a sample was sequenced may provide information about potential biases in sequencing strategy. Provide the purpose of sequencing from the picklist in the template. The reason for sample collection should be indicated in the "purpose of sampling" field.	Travel-associated surveillance			1.0.0	1.0.0	1.0.0
Sequence information	purpose of sequencing details	GENEPIO:0001446	The description of why the sample was sequenced providing specific details.	Provide an expanded description of why the sample was sequenced using free text. The description may include the importance of the sequences for a particular public health investigation/surveillance activity/research question. Suggested standardized descriptions include. Assessing public health control measures, Determining early introductions and spread, Investigating arimien-related exposures, Investigating remote regions, Investigating health care workers, Investigating schools/universities.	Investigating schools/universities			1.0.0	1.0.0	1.0.0
equence information	sequenced by	GENEPIO:0100416	The name of the agency, organization or institution responsible for sequencing the isolate's genome.	Provide the name of the agency, organization or institution that performed the sequencing in full (avoid abbreviations). If the information is unknown or cannot be provided, leave blank or provide a null value.	Public Health Agency of Canada (PHAC) [GENEPIO:0100551]			3.0.0	3.0.0	3.0.0
Sequence information	sequenced by contact name	GENEPIO:0100471	The name or title of the contact responsible for follow-up regarding the sequence.	Provide the name of an individual or their job title. As personnel turnover may render the contact's name obsolete, it is more prefereable to provide a job title for ensuring accuracy of information and institutional memory. If the information is unknown or cannot be provided, leave blank or provide a null value.	Enterics Lab Manager			3.0.0	3.0.0	3.0.0
Sequence information	sequenced by contact email	GENEPIO:0100422	The email address of the contact responsible for follow-up regarding the sequence.	Provide the email associated with the listed contact. As personnel turnover may render an individual's email obsolete, it is more prefereable to provide an address for a position or lab, to ensure accuracy of information and institutional memory. If the information is unknown or cannot be provided, leave blank or provide a null value.	enterics@lab.ca			3.0.0	3.0.0	3.0.0
Sequence information	sequence submitted by	GENEPIO:0001159	The name of the agency that submitted the sequence to a database.	The name of the agency should be written out in full, (with minor exceptions) and be consistent across multiple submissions. For Canadian institutions submitting specimens rather than sequencing data, please put the "National Microbiology Laboratory (MML)".	Public Health Ontario (PHO)			1.0.0	1.0.0	1.0.0
Sequence information	sequence submitter contact email	GENEPIO:0001165	The email address of the contact responsible for follow-up regarding the sequence.	The email address can represent a specific individual or laboratory.	RespLab@lab.ca			1.0.0	1.0.0	1.0.0
Sequence information	sequencing date	GENEPIO:0001447	The date the sample was sequenced.	ISO 8601 standard "YYYY-MM-DD".	2020-06-22			1.0.0	1.0.0	1.0.0
Sequence information	library ID	GENEPIO:0001448	The user-specified identifier for the library prepared for sequencing.	The library name should be unique, and can be an autogenerated ID from your LIMS, or modification of the	XYZ_123345			1.0.0	1.0.0	1.0.0
Sequence information	sequencing platform	GENEPIO:0100473	The platform technology used to perform the sequencing.	isolate ID. Provide the name of the company that created the sequencing instrument by selecting a value from the template pick list. If the information is unknown or cannot be provided, leave blank or provide a null value.	Illumina [GENEPIO:0001923]			1.0.0	1.0.0	1.0.0
Sequence information	sequencing instrument	GENEPIO:0001452	The model of the sequencing instrument used.	Provide the model sequencing instrument by selecting a value from the template pick list. If the information is unknown or cannot be provided, leave blank or provide a null value.	Illumina HiSeq 2500 [GENEPIO:0100117]			1.0.0	1.0.0	1.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Label ID	precated Version Tracking	ID.	Domini
	Colour Code Legend						Label	ID	Description/ dance
Sequence information	sequencing assay type	GENEPIO:0100997	The overarching sequencing methodology that was used to determine the sequence of a biomaterial.	Example Guidance: Provide the name of the DNA or RNA sequencing technology used in your study. If unsure refer to the protocol documentation, or provide a null value.	whole genome sequencing assay		1.0.0	1.0.0	1.0.0
Sequence information	library preparation kit	GENEPIO:0001450	The name of the DNA library preparation kit used to generate the library being sequenced.	Provide the name of the library preparation kit used.	Nextera XT		1.0.0	1.0.0	1.0.0
Sequence information	sequencing protocol	GENEPIO:0001454	The protocol or method used for sequencing.	Provide the name and version of the procedure or protocol used for sequencing. You can also provide a link to a protocol online.	https://www.protocols.io/view/ncov-2019-sequencing-protocol-bbmuik6w?versionwaning=no		1.0.0	1.0.0	1.0.0
Sequence information	amplicon pcr primer scheme	GENEPIO:0001456	The specifications of the primers (primer sequences, binding positions, fragment size generated etc) used to generate the amplicons to be sequenced.	Provide the name and version of the primer scheme used to generate the amplicons for sequencing.	artic v3		1.0.0	1.0.0	1.0.0
Sequence information	amplicon size	GENEPIO:0001449	The length of the amplicon generated by PCR amplification.	Provide the amplicon size expressed in base pairs.	300		1.0.0	1.0.0	1.0.0
Sequence information	DNA fragment length	GENEPIO:0100843	The length of the DNA fragment generated by mechanical shearing or enzymatic digestion for the purposes of library preparation.	Provide the fragment length in base pairs (do not include the units).	400		1.0.0	1.0.0	1.0.0
Sequence information	genomic target enrichment method	GENEPIO:0100966	The molecular technique used to selectively capture and amplify specific regions of interest from a genome.	Provide the name of the enrichment method	hybrid selection method		1.0.0	1.0.0	1.0.0
Sequence information	genomic target enrichment method details	GENEPIO:0100967	Details that provide additional context to the molecular technique used to selectively capture and amplify specific regions of interest from a genome.	Provide details that are applicable to the method you used.	enrichment was done using Twist's respiratory virus research panel: https://www.twistbioscience.com/products ngs/fixed-panels/respiratory-virus-research-panel		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics		GENEPIO:0001457							
Bioinformatics and QC metrics	quality control method name	GENEPIO:0100557	The name of the method used to assess whether a sequence passed a predetermined quality control threshold.	Providing the name of the method used for quality control is very important for interpreting the rest of the QC information. Method names can be provided as the name of a pipeline or a link to a GitHub repository. Multiple methods should be listed and separated by a semi-colon. Do not include QC tags in other fields if no method name is provided.			1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	quality control method version	GENEPIO:0100558	The version number of the method used to assess whether a sequence passed a predetermined quality control threshold.	Methods updates can make big differences to their outputs. Provide the version of the method used for quality control. The version can be expressed using whatever convention the developer implements (e.g. date, semantic versioning). If multiple methods were used, record the version numbers in the same order as the method names. Separate the version numbers using a semi-colon.	1.2.3		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	quality control determination	GENEPIO:0100559	The determination of a quality control assessment.	Select a value from the pick list provided. If a desired value is missing, submit a new term request to the PHA4GE QC Tag GitHub issuetracker using the New Term Request form.	sequence failed quality control		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	quality control issues	GENEPIO:0100560	The reason contributing to, or causing, a low quality determination in a quality control assessment.	Select a value from the pick list provided. If a desired value is missing, submit a new term request to the PHA4GE QC Tag GitHub issuetracker using the New Term Request form.	low average genome coverage		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	quality control details	GENEPIO:0100561	The details surrounding a low quality determination in a quality control assessment.		CT value of 39. Low viral load. Low DNA concentration after amplification.		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	raw sequence data processing method	GENEPIO:0001458	The method used for raw data processing such as removing barcodes, adapter trimming, filtering etc.	Provide the software name followed by the version or a link to the github protocol e.g. Trimmomatic v. 0.38, Porechop v. 0.2.3	Porechop 0.2.3		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	dehosting method	GENEPIO:0001459		Provide the name and version number of the software used to remove host reads.	Nanostripper		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	consensus sequence software name	GENEPIO:0001463	The name of the software used to generate the consensus sequence.	Provide the name of the software used to generate the consensus sequence.	iVar		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	consensus sequence software version	GENEPIO:0001469	The version of the software used to generate the consensus sequence.	Provide the version of the software used to generate the consensus sequence.	1.3		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	sequence assembly software name	GENEPIO:0100825	The name of the software used to assemble a sequence.	Provide the name of the software used to assemble the sequence.	SPAdes Genome Assembler, Canu, wtdbg2, velvet		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	sequence assembly software version	GENEPIO:0100826	The version of the software used to assemble a sequence.	Provide the version of the software used to assemble the sequence.	3.15.5		1.0.0	1.0.0	1.0.0
Sioinformatics and QC metrics	breadth of coverage value	GENEPIO:0001472	The percentage of the reference genome covered by the sequenced data, to a prescribed depth.	Provide value as a percent.	95		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	depth of coverage value	GENEPIO:0001474	The average number of reads representing a given nucleotide in the reconstructed sequence.	Provide value as a fold of coverage.	400		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	depth of coverage threshold	GENEPIO:0001475	The threshold used as a cut-off for the depth of coverage.	Provide the threshold fold coverage.	100		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	genome completeness	GENEPIO:0100844	The percentage of expected genes identified in the genome being sequenced. Missing genes indicate missing genomic regions (incompleteness) in the data.	Provide the genome completeness as a percent (no need to include units).	85		1.0.0	1.0.0	1.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated D Label II			
	Colour Code Legend						Label	ID	Description/edance
ioinformatics and QC metrics	number of base pairs sequenced	GENEPIO:0001482	The number of total base pairs generated by the sequencing process.	Provide a numerical value (no need to include units).	387566		1.0.0	1.0.0	1.0.0
ioinformatics and QC metrics	number of total reads	GENEPIO:0100827	The total number of non-unique reads generated by the sequencing process.	Provide a numerical value (no need to include units).	423867		1.0.0	1.0.0	1.0.0
ioinformatics and QC metrics	number of unique reads	GENEPIO:0100828	The number of unique reads generated by the sequencing process.	Provide a numerical value (no need to include units).	248236		1.0.0	1.0.0	1.0.0
ioinformatics and QC metrics	minimum post-trimming read length	GENEPIO:0100829	The threshold used as a cut-off for the minimum length of a read after trimming.	Provide a numerical value (no need to include units).	150		1.0.0	1.0.0	1.0.0
ioinformatics and QC metrics	number of contigs	GENEPIO:0100937	The number of contigs (contiguous sequences) in a sequence assembly.	Provide a numerical value.	10		1.0.0	1.0.0	1.0.0
ioinformatics and QC metrics	percent Ns across total genome length	GENEPIO:0100830	The percentage of the assembly that consists of ambiguous bases (Ns).	,	2		1.0.0	1.0.0	1.0.0
ioinformatics and QC metrics	Ns per 100 kbp	GENEPIO:0001484	The number of ambiguous bases (Ns) normalized per 100 kilobasepairs (kbp).	, ,	342		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	N50 value	GENEPIO:0100938	The length of the shortest read that, together with other reads, represents at least 50% of the nucleotides in a set of sequences.	Provide the N50 value in Mb.	150		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	percent read contamination	GENEPIO:0100845	The percent of the total number of reads identified as contamination (not belonging to the target organism) in a sequence dataset.		2		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	consensus genome length	GENEPIO:0001483	The length of the genome defined by the most common nucleotides at each position.	Provide a numerical value (no need to include units).	38677		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	sequence assembly length	GENEPIO:0100846	The length of the genome generated by assembling reads using a scaffold or by reference-based mapping.	Provide a numerical value (no need to include units).	34272		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	reference genome accession	GENEPIO:0001485	A persistent, unique identifier of a genome database entry.	Provide the accession number of the reference genome.	NC_045512.2		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	deduplication method	GENEPIO:0100831	The method used to remove duplicated reads in a sequence read dataset.	Provide the deduplication software name followed by the version, or a link to a tool or method.	DeDup 0.12.8		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	read mapping software name	GENEPIO:0100832	The name of the software used to map sequence reads to a reference genome or set of reference genes.	Provide the name of the read mapping software.	Bowtie2, BWA-MEM, TopHat		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	read mapping software version	GENEPIO:0100833	The version of the software used to map sequence reads to a reference genome or set of reference genes.	Provide the version number of the read mapping software.	2.5.1		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	taxonomic reference database name	GENEPIO:0100834	The name of the taxonomic reference database used to identify the organism.	Provide the name of the taxonomic reference database.	NCBITaxon		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	taxonomic reference database version	GENEPIO:0100835	The version of the taxonomic reference database used to identify the organism.	Provide the version number of the taxonomic reference database.	1.3		1.0.0	1.0.0	1.0.0
Bioinformatics and QC metrics	read mapping criteria	GENEPIO:0100836	A description of the criteria used to map reads to a reference sequence.	Provide a description of the read mapping criteria.	Phred score >20		1.0.0	1.0.0	1.0.0
Sioinformatics and QC metrics	bioinformatics protocol	GENEPIO:0001489	A description of the overall bioinformatics strategy used.	Further details regarding the methods used to process raw data, and/or generate assemblies, and/or generate consensus sequences can. This information can be provided in an SOP or protocol or pipeline/workflow. Provide the name and version number of the protocol, or a GitHub link to a pipeline or workflow.	https://github.com/phac-nml/ncov2019-art c-nf	<u>ti</u>	1.0.0	1.0.0	1.0.0
athogen diagnostic testing		GENEPIO:0001506							
Pathogen diagnostic testing	organism	GENEPIO:0001191	The taxonomic name of the organism.	Put the genus and species (and subspecies if applicable) if known. The standardized term can be sourced from this look-up service: https://www.ebi.ac.uk/ols4/ontologies/ncbitaxon	Severe acute respiratory syndrome coronavirus 2		1.0.0	1.0.0	1.0.0
athogen diagnostic testing	gene name	GENEPIO:0100655	The name of the gene used in the diagnostic RT-PCR test.	Provide the full name of the gene used in the test. The gene symbol (short form of gene name) can also be provided. Standardized gene names and symbols can be found in the Gene Ontology using this look-up service: https://bit.ly2Sq1Lbl			1.0.0	1.0.0	1.0.0
Pathogen diagnostic testing	diagnostic target presence	GENEPIO:0100962	The binary value of the result from a diagnostic test.	Select a value from the pick list provided, to describe whether a target was determined to be present or absent within a sample.	present		1.0.0	1.0.0	1.0.0
Pathogen diagnostic testing	diagnostic measurement value	GENEPIO:0100963	The value of the result from a diagnostic test.	Provide the numerical result of a diagnostic test.	1000		1.0.0	1.0.0	1.0.0
Pathogen diagnostic testing	diagnostic measurement unit	GENEPIO:0100964	The unit of the result from a diagnostic test.	Select a value from the pick list provided, to describe the units of the given diagnostic test.	CFU/mL		1.0.0	1.0.0	1.0.0
Pathogen diagnostic testing	diagnostic measurement method	GENEPIO:0100965	The method by which a diagnostic result was received.	Select a value from the pick list provided to describe the method used for a given diagnostic test.	qPCR		1.0.0	1.0.0	1.0.0
Contributor acknowledgement		GENEPIO:0001516							
Contributor acknowledgement	authors	GENEPIO:0001517	Names of individuals contributing to the processes of sample collection, sequence generation, analysis, and data submission.	Include the first and last names of all individuals that should be attributed, separated by a comma.	Tejinder Singh, Fei Hu, Joe Blogs		1.0.0	1.0.0	1.0.0